

# In the box


Action Camera

**USB** Cable











# Setting up your camera



1. Connect the camera to your computer using the included USB cable.

3. The battery indicator is located on the lower left corner of the camera's LCD








2. Insert the Micro SD card into the card slot (as shown below) until it clicks and locks into place.





ord con only be inserted one woy: do not use force when inserting the cord. Inserting or removing a cord while the comero is an may domage the cord, files stored on the cord.

### Location of controls




# Micro SD Card Slot

### Turning the camera on/off

### 1. To turn the camera on, press and HOLD the [POWER] button until the display turns on.

2. To turn the camera off, press and HOLD the [POWER] button until the display turns off.



is comero hos on outo-shutoff feoture which con be set for specific times (refer to System Settings > Power Sove).

### **Using the Camera Mode Selector Switch**

### Camera Mode Selector

This camera has three different modes depending on what you are doing with the camera. For example:

A) To take pictures switch the [Camera Mode Selector] all the way up to the picture mode position. B) To take videos switch the [Camera Mode Selector] to the middle,

video mode position. C) To playback pictures/videos switch the [Camera Mode Selector] to the



# Picture Mode

### I. Make sure that a Micro SD card is inserted into the camera.

2. Turn on the camera, and switch the [Camera Mode Selector] to picture

B. Press the [SHUTTER / BACK] button to take a picture.



'. Pictures Remaining 8. Micro SD Card Indicator 9. Zoom level 10. Battery Indicator

Self timer and continuous shooting While in picture mode, press the [MENU / SELECT] button, then press the [DOWN / ZOOM - ] button till you see the [Driver Mode], press the [MENU / **SELECT**] button to select it. 2. Use the arrows to select from 2 second self-timer, 10 second self-timer or Burst.

3. When you select 2 or 10 seconds self timer, the timer starts counting down

Zooming in & Out -In picture of video mode press the up and down arrow keys

from 2 or 10 seconds, and the camera takes a picture; when you select burst, the camera takes 3 pictures continuously. 4. Press the [SHUTTER / BACK] button to start self timer or burst snapshot. 5. To turn off the self timer or Burst feature repeat step 1 then select "Off".

# Video Mode

### 1. Make sure that a Micro SD card is inserted into the camera.

2. Turn on the camera, and switch the [Camera Mode Selector] to video

3. Press the [SHUTTER / BACK] button, the camera starts recording video

4. To stop recording press the [SHUTTER / BACK] button again.



# **▶** Playback Mode



### 1. Turn on the camera, and switch the [CAMERA MODE SELECTOR] to playback

2. Use the [▲] or [▼] buttons to scroll through picture and video files.

### Video Playback

1. If you select a video, press the [SHUTTER / BACK] button to start the

2. To stop the video playback press the [MENU / SELECT] button.



## **Connecting the camera**

To edit or upload and share your videos and pictures, you must first transfer them to your computer. Follow the steps below to connect the camera to your

1. Make sure the camera is turned off, and that a Micro SD card is inserted in the camera before connecting it to your computer.

2. Insert the smaller end of the USB cable into the camera's USB port.

5. Autoplay will prompt your device is connected.

6. On your PC select "open folder" to view files.

7. Select "DCIM" then select "100MEDIA".

9. Before disconnecting the camera, click on the "Safely Remove Hardware" icon usually located on the lower right corner of your desktop.

the drop down menu.

### Please do not disconnect the USB coble during loading, os it may couse domage to the comero and the files on the SD cord.

### াম System Settings

### To make changes to the camera's settings, follow the instructions below:

1. Press the [MENU / SELECT] Button. 2. Quickpress the [POWER] Button. 3. Use the [▲] or [▼] buttons to scroll through the settings. 4. Press the [MENU / SELECT] button to select the desired setting.



### System Settings Ontions

System Settings Options	
<b>AUTO REVIEW</b>	Set time of review after picture is taken (off, 1 sec, 3 sec).
POWER FREQUENCY	50Hz / 60Hz (The Camera's default setting is 60hz for the USA and North Americ
POWER SAVE	Select off,1,3, or 5 minutes. To conserve battery power, the camer will shut off if no buttons are pressed within the selected time.
DATE & TIME	Set the camera's date and time.
LANGUAGE	Set the camera's language
FORMAT	Erase all data on the SD card
RESET ALL	Reset the camera's settings to factory default.

# Picture Mode Settings

1. Switch the [Camera Mode Selector] to picture mode. 2. Press the [MENU / SELECT] Button. 3. Use the [▲] or [▼] buttons to scroll through the settings. 4. Press the [MENU / SELECT] button to select the desired setting.



### **Picture Mode Settings Options**

RESOLUTION	1M (1280x960) / 3M (2048x1536) / 5M (2592x1944) (Higher picture resolution takes up more space on the SD card).
QUALITY	Super fine / Fine / Normal
METERING	Center / Multi / Spot
WHITE BALANCE	Auto / Daylight / Cloudy / Fluorescent / Tungsten
EXPOSURE	Adjust the exposure
DRIVER MODE	"Off" (disables the self timer), "2" or "10" second options (self timer), "Burst" (3 frame shot)
EFFECT	Norma / B&W / Sephia / Negative / Red / Green / Blue

# **Video Mode Settings**

### To make changes to the picture mode settings, follow the instructions below: To make changes to the video mode settings, follow the instructions below:

1. Switch the [Camera Mode Selector] to video mode.

2. Press the [MENU / SELECT] Button. 3. Use the  $[\blacktriangle]$  or  $[\blacktriangledown]$  buttons to scroll through the settings. 4. Press the [MENU / SELECT] button to select the desired setting.



### Video Mode Settings Options

video Mode Settings Options		
MOVIE SIZE	HD 1280X720 / 640X480 / 320X240	
RECORDING INTERVAL	Select OFF, 1, 3, or 5 minutes.	
METERING	Center / Multi / Spot	
WHITE BALANCE	Auto / Daylight / Cloudy / Fluorescent / Tungsten	
EFFECT	NOR / B&W / SEPIA / NEGATIVE / RED / GREEN / BLUE	
DATE STAMP	OFF / DATE / DATE & TIME	

# Playback Mode Settings

To make changes to the playback mode settings, follow the instructions below:

1. Switch the [Camera Mode Selector] to playback mode. 2. Press the [MENU / SELECT] Button. 3. Use the  $[\blacktriangle]$  or  $[\blacktriangledown]$  buttons to scroll through the settings. 4. Press the [MENU / SELECT] button to select the desired setting.


### Playback Mode Settings Screen




### **Playback Mode Settings Options**

LOCK	Lock one or all of your picture and video files. When locked the fil will not be to be deleted.
DELETE	"One" (Delete the currently displayed video or picture) or "All"
SLIDE SHOW	Start a slide show, and adjust the slide show settings.


# **Mount Kit Assembly**



# **Helmet Mount**



# **Bike Mount**



### Waterproof case

### Assembling camera into case


Your action cam comes with a water proof case for underwater action and added durability. To assemble your camera to the case, follow the instructions below:

1. Open the latch on the water proof case. 2. Insert the camera lens forward into the case.

3. Close the door and secure the latch.

**FCC** information

NOTE: Please make sure latch is secure and that all seals are in place to ensure no water can seep in.



### Assembling camera to bike mount

the the camera to the bike mount, follow the instructions below:

**NOTE:** Use the included rubber swatch to mount it securely.

2. Use the included screw to secure the bike mount, tighten till the bike mount is

3. With the camera assembled to the water proof case or included shield align the bolt on the attachment buckle to the hole on your waterpoof case or shield **NOTE:** You must either use the waterproof case or shield to assemble the camera and turn. When the desired position is reached, you can use the wheel on the bottom end of the bolt to tighten.

on the attachment buckle and sliding it on to the mount.

**NOTE:** You must either use the waterproof case or shield to assemble the camera to the attachment buckle.

### This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this equipment not expressly approved

by the party responsible for compliance could void the user's authority to NOTE: This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if

not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help.

## **Bike Mount Assembly**

### Your action cam includes the necessary accessories for bike action. To assemble

1. Install the bike mount onto your bikes handle bars by putting the bottom half of your bike mount onto the handle bar and connecting it to the top part of

4. Connect the attachment buckle to the bike mount by pinching both sides

### Limited Warranty

In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center

### TO OBTAIN WARRANTY SERVICE:

for repair or exchange.

- Provide proof of the date of purchase within the package (Dated
- Prepay all shipping costs to the authorized service center, and remember to insure your return. • Include a return shipping address (no P.O. Boxes), a telephone
- contact number, and the defective unit within the package. • Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

### The shipping address of the authorized service center is:

Helmet assembly

bottom end of the bolt to tighten.

to the attachment buckle.

Assembling camera to helmet mount

on the attachment buckle and sliding it on to the mount.

and velcro the mount through the holes on your helmet.

Your action cam includes the necessary accessories for helmet action. To

assemble the the camera to the helmet mount, follow the instructions below:

1. With the camera assembled to the water proof case or included shield align

Connect the attachment buckle to the helmet mount by pinching both sides

3. Insert the helmet strap through the slots on the side of the helmet mount

the bolt on the attachment buckle to the hole on your waterpoof case or shield

and turn. When the desired position is reached, you can use the wheel on the

Southern Telecom, Inc. Attention: Customer Service (2nd Floor) 14-C 53rd Street Brooklyn, NY 11232

Should you have any questions or problems concerning this product, please contact our customer service department at:

### **Customer Support:** 2 1-877-768-8483 (Toll Free) ⊠ cs@southerntelecom.com

Monday - Thursday: 9AM - 5PM (EST) Friday: 9AM - 3PM (EST)

www.southerntelecom.com

Warranty service not provided This warranty does not cover damage resulting from accident, misuse, abuse. improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

### **Limitation of Warranty:**

THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY AIT, INC. IT'S AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE. Some states do not allow the exclusion nor limitation of incidental or consequential

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE

REMEDY OF THE CONSUMER. AIT, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR

damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.



**DATE STAMP** OFF / DATE & TIME














Camera Shield


Attachment Buckle


2. The Charging indicator light will illuminate red.

# Using your camera



# bottom position, playback mode.





# Connect your camera to a computer

3. Connect the larger end of the USB cable into your computer's USB port.

8. Pictures and videos will be be displayed in this folder.

# Click on "My Computer", RIGHT click on "MICROSD" then click on "Eject" from